

Somax Limited 45a Rodney Road, Backwell Bristol, BS48 3HW

> t: 01275 465 555 f: 01275 464 949 email: info@somax.eu.com

> > VAT No: 886 2020 22

Uncoupling:

- 1. Apply the trailer brake (red button towards you)
- 2. Wind down the trailer leg
- 3. Disconnect the suzies (yellow first) and secure onto the trailer
- 4. Open the coupling, check to see that the red 'nipple' has withdrawn
- 5. Pull forward a park alongside the trailer
- 6. Tell the examiner that you would usually adjust the bumper and remove the number plate

The examiner will now tell you to recouple but this time "Imagine it is a trailer you have not seen before"

Recoupling:

- Before you reverse, walk around the vehicle checking that THE RED TRAILER PARKING BRAKE is applied. Check general condition, tyres, lights etc
- 2. Open the coupling, check to see that the red 'nipple' has withdrawn
- 3. Select reverse and switch the camera onto the coupling, then reverse slowly onto the trailer eye until you hear a loud 'clunk' and watch the coupling handle engage
- 4. Select 'D' and attempt to pull forward twice. Apply parking brake and switch off
- 5. Check that the red 'nipple' is now flush
- 6. Apply the suzie's starting with the red line
- 7. Wind up trailer legs
- 8. Release the trailer brake
- 9. Ask the examiner for help with the lights









